



Innovative
Heat Treatment

124 - 6227 2nd St SE
Calgary, Alberta,
Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: wecare@ihttech.com

Q & A – QUESTIONS AND ANSWERS





Innovative
Heat Treatment

124 - 6227 2nd St SE

Calgary, Alberta,

Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: wecare@ihttech.com

Q & A – QUESTIONS AND ANSWERS

1. **Issue** - [Changing the upper limit of the set point](#)



Innovative Heat Treatment

124 - 6227 2nd St SE
Calgary, Alberta,
Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: wecare@ihttech.com

Step 1: Press and hold the menu button UNTIL YOU SEE "LEv3 GOTO" as shown below:



Step 2: Press the up arrow to show "CONF goto.""





Innovative Heat Treatment

124 - 6227 2nd St SE

Calgary, Alberta,

Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: wecare@ihttech.com

Step 3: Press the "Enter" button.



Step 4: Then using the enter button and the up/down arrows enter the code as 0004. Then press the enter button again and you will get the screen to look as below:





Innovative Heat Treatment

124 - 6227 2nd St SE
Calgary, Alberta,
Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: wecare@ihttech.com

Step 5: Press the menu button until you see "LOOP List" as shown below:



Step 6: Press the enter button 1 time to get the "mAIN S List"





Innovative
Heat Treatment

124 - 6227 2nd St SE

Calgary, Alberta,

Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: wecare@ihttech.com

Step 7: Press the Up arrow until you see "SP S.List" as shown here



Step 8: Press the Enter key and then press the up arrow to set your upper limit to 2300 (or whatever your max is) as shown here:





Innovative Heat Treatment

124 - 6227 2nd St SE
Calgary, Alberta,
Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: wecare@ihttech.com

Step 9: Press the enter key until you see SP.HI and set that to the same number as in the previous step.



Step 10: Press the Menu button until you see the option "ALLIST" as shown below





Innovative Heat Treatment

124 - 6227 2nd St SE
Calgary, Alberta,
Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: wecare@ihttech.com

Step 11: Press the Enter key until you see "RNG .HI".



Step 12: Press and hold the Up arrow until you go above the max temperature you want to heat to. In the image below we set it to 2300.





Innovative
Heat Treatment

124 - 6227 2nd St SE
Calgary, Alberta,
Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: wecare@ihttech.com

Step 13: Press and hold the menu key until you see "LEv 1 goto" and then press the enter key. Then it is done.