



**Innovative**  
Heat Treatment

124 - 6227 2nd St SE  
Calgary, Alberta,  
Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: [wecare@ihttech.com](mailto:wecare@ihttech.com)

## Q & A – QUESTIONS AND ANSWERS





**Innovative**  
**Heat Treatment**

124 - 6227 2nd St SE

Calgary, Alberta,

Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: [wecare@ihttech.com](mailto:wecare@ihttech.com)

## Q & A – QUESTIONS AND ANSWERS

1. Issue - SETTING THE MAXIMUM ALLOWABLE THERMOCOUPLE READING ON THE EURO THERM CONTROLLER.



# Innovative Heat Treatment

124 - 6227 2nd St SE  
Calgary, Alberta,  
Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: [wecare@ihttech.com](mailto:wecare@ihttech.com)

**Step 1:** Press and hold the menu button UNTIL YOU SEE "LEv3 GOTO" as shown below:



**Step 2:** Press the up arrow to show "CONF goto.""





# Innovative Heat Treatment

124 - 6227 2nd St SE  
Calgary, Alberta,  
Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: [wecare@ihttech.com](mailto:wecare@ihttech.com)

**Step 3:** Press the "Enter" button.



**Step 4:** Then using the enter button and the up/down arrows enter the code as 0004. Then press the enter button again and you will get the screen to look as below:





# Innovative Heat Treatment

124 - 6227 2nd St SE  
Calgary, Alberta,  
Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: [wecare@ihttech.com](mailto:wecare@ihttech.com)

**Step 5:** Press the Menu button until you see the option "AI LIST" as shown below:



**Step 6:** Press the Enter key until you see "RNG .HI"





# Innovative Heat Treatment

124 - 6227 2nd St SE  
Calgary, Alberta,  
Canada, T2H 1J5

WEB: <https://innovativeheattreatment.com>

PHONE: (403) 980-5213

EMAIL: [wecare@ihttech.com](mailto:wecare@ihttech.com)

**Step 7:** Press and hold the Up arrow until you go above the max temperature you want to heat to. In the image below we set it to 2300.



**Step 8:**

Press and hold the menu key until you see "LEv 1 goto" and then press the enter key. Then it is done